


# TE<sup>X</sup>H TIPS

Pioneer


## IMPORTANT NOTICE FOR PIONEER DMH-WT6000NEX WHEN USING WIRED REMOTE ADAPTER

Please note the following and important change on our Pioneer DMH-WT6000NEX and its use with a wired remote control interface (Steering wheel control).



When using a stand-alone steering wheel interface connected to our **DMH-WT6000NEX** via the « **W/R INPUT** » jack (Wired Remote Input), **you must now enable the communication** which is by default set to «OFF».

The activation of this W/R INPUT is available under the system configuration menu.



\* This does not apply to any 4-pin data-bus interface (iDatalink Maestro RR or Metra Axxess).